# **CHILTON**LIBRARY



# **Removal & Installation**

#### **REMOVAL AND INSTALLATION**

## **REMOVAL**

- 1. Disconnect and isolate the battery negative cable.
- 2. Remove the overhead console. (Refer to Body/Interior/CONSOLE, Overhead/Removal and Installation).
- 3. Using a suitable flat bladed tool, release the mounting tabs from the sides of the sunroof control switch and pull the switch out of the overhead console assembly.

### **INSTALLATION**

- 1. Insert the sunroof control switch into the overhead console assembly. Push the switch until it is securely held in place by the mounting tabs.
- 2. Install the overhead console. (Refer to Body/Interior/CONSOLE, Overhead/Removal and Installation).
- 3. Connect the battery negative cable.