# **CHILTON**LIBRARY



# **Removal & Installation**

#### **REMOVAL AND INSTALLATION**

#### **REMOVAL**



- 1. Remove the front seat (Refer to Body/Seats/SEAT/Removal and Installation)(Refer To List 1).
- 2. If equipped with recliner and height adjust handles, use a small flat bladed tool and remove the handle screw covers. Remove the screws then pull each handle to remove.
- 3. Remove the screws (2) at the front and back of the outboard side shield (3).
- 4. Pull out at the bottom to release the retaining clips, then push forward and lift to remove.
- 5. Disconnect the wire harness connectors from the switches (1).



- 6. Remove the screws (1) at the front and back of the inboard side shield (2).
- 7. Pull out at the bottom to release the retaining clips, then push forward and lift to remove.

#### **INSTALLATION**



- 1. Position the inboard side shield (2) and engage the retaining clips.
- 2. Install the recliner and height adjust handles, if equipped.
- 3. Install the screws (1) and tighten securely.



- 4. Connect the wire harness connectors to the switches (1).
- 5. Position the outboard side shield (3) and engage the retaining clips.
- 6. Install the screws (2) and tighten securely.

## **Refer To List:**

## List 1

- 23 Body / Seats, First Row / SEAT, Front / Removal and Installation
- 23 Body / Seats, Second Row, Stow-n-Go / SEAT, Stow-n-Go / Removal and Installation
- 23 Body / Seats, Third Row, Stow-n-Go / SEAT / Removal and Installation
- 23 Body / Seats, Third Row, Power Folding / SEAT / Removal and Installation